

Volume

1.1

OPERATIONAL MANUAL

MODEL: H300 TRIPOD STAND



by BLUEROCK® Tools

H 300 TRIPOD STAND

UNPACKING THE ITEM

Caution: This device is packed together with items that may be sharp, oily and overly heavy objects. Remove the device from the packaging in a safe manner. Check to ensure all accessories are included with the item while unpacking. If any parts are found to be missing, contact the retailer as soon as possible. Do not throw away the packaging until the item is out of the guarantee period. Dispose of the packaging in an environmentally responsible manner. Recycle if possible. Keep all plastic bags away from children due to risk of suffocation.

© THE NEWMAN TRADING COMPANY LLC DBA BLUEROCK® TOOLS 2016
1100 SW 16th St • Suite D
Renton, WA 98057
Phone 206.604.8363 • Fax 425.572.5167
www.bluerocktools.com

Table of Contents

<u>SAFETY</u>	1
<i>PRE-OPERATIONAL SAFETY CHECKS</i>	1
<i>OPERATIONAL SAFETY CHECKS</i>	1
<u>OPERATIONS</u>	2
<i>PURPOSE</i>	2
<i>TRANSPORTING THE DEVICE</i>	2
<i>SETTING UP THE DEVICE</i>	2
<u>GENERAL MAINTENANCE</u>	2
<u>PARTS LIST</u>	3
<u>BREAKDOWN VIEW</u>	3

BLUEROCK® TOOLS

Safety

DO NOT USE THIS DEVICE UNLESS YOU HAVE READ THE OPERATING INSTRUCTIONS!



Safety glasses must be worn at all times in work areas. Use a full face mask whenever possible.



Long and loose hair must be contained.



Appropriate footwear must be worn.



Close fitting/protective clothing must be worn.



Safety gloves should be worn at all times and jewelry must not be worn.



Hearing protection should be worn when using this device.



Read operational manual prior to use.



Dust mask must be worn while using certain devices.

PRE-OPERATIONAL SAFETY CHECKS

- Examine the body of the device and inspect for damage or defects.

OPERATIONAL SAFETY CHECKS

- ONLY to be operated by qualified personal who have read instructions.
 - NOTE: Failure to read and follow instructions could result in electrical shock, fire, property damage and/or serious injury!
- DO ensure all non-essential people are clear of the immediate work area.
- Stay alert and use common sense when using this stand.
- DO NOT make adjustments to device while under load on base.
- DO NOT operate device outside of device specifications.
- DO NOT allow children or untrained personal to operate device.
- DO NOT use this device in the rain or a wet environment. If using outdoors, make sure the surface is clean and dry.
- DO NOT operate this device on the same work surface where welding is being performed. This could result in severe damage to the device or personal injury to the user.

Operations

Note

THOROUGHLY READ THROUGH THE ENTIRE MANUAL BEFORE OPERATING THIS DEVICE!

SERVICING SHOULD ONLY BE DONE BY A QUALIFIED TECHNICIAN

PURPOSE

- The purpose of the H300 stand is to use as a base for certain machinery.

TRANSPORTING THE DEVICE

- When transporting the device, always carry with two handles.
- If transporting inside a vehicle, it is recommended to transport it on its side with the legs collapsed so as to avoid the item falling over.

SETTING UP THE DEVICE

- Locate a clean, level and stable place where the stand will be placed.
- Place stand with the feet on the floor and slowly open the tripod legs. Carefully push down on the center of the tool tray until the tray is locked into position.
 - CAUTION: Be mindful of fingers and hands as pinch-points can develop during this procedure.
- To collapse the stand, push up on the tray to unlock. Be careful of the moving legs coming towards you during this procedure.
- The stand can be anchored to provide greater stability. There are holes at the base of the legs that allow for bolts.
 - CAUTION: Always anchor the feet when placing large power drives, pipe threaders or other large/heavy machinery on the stand to prevent tipping.

General Maintenance

- Keep device clean and free of debris.
- Check for misalignment, binding and breakage of all moving parts. If damaged, repair tool before use.

Parts List

Part Number	Description	Part Number	Description
	Stand complete	9	Pin /w washer
1	Tool tray	10	X-washer
2	Base	11	Set screw
3	Tray & Leg Assembly	12	Chain assembly
4	Tray support	13	Front leg (2)
5	Bolt	14	Rear leg
6	Bolt	15	Wing nut
7	Nut	16	Grommet
8	Lock washer	17	Washer

Breakdown View

